



1. Carefully place the bath into position ensuring the floor is clean, flat and level.

2. Mark the outline of the bath shape on the floor and the bath waste position.

3. Using the bath trap dimensions determine the waste pipe outlet position.

4. Allow sufficient depth within the sub-floor to allow for the bath trap and waste pipe outlet.

5. Carefully tilting the bath connect the chrome bath waste to the bath.

6. Fit the bath trap to the waste outlet pipe.

7. Fit the bath trap to the bath waste

8. Apply a silicone bead to the previously marked bath floor outline and reposition the bath.

9. Check the bath levels again and leave the silicone to cure for 24 hours.

For help and advice on **Livinghouse** stone resin baths please contact us by phone, email or visit our website.

**Tel:** 01722 415000  
**Email:** sales@livinghouse.co.uk  
**Website:** www.livinghouse.co.uk

**Livinghouse** stone resin baths are available to view from our Salisbury showroom please contact us for more details.

**Showroom address**  
**Livinghouse**  
 Unit 3 Ashfield Trading Estate  
 Ashfield Road  
 Salisbury  
 Wiltshire  
 SP2 7HL