



## Important installation notes

Tiles need to be adhered with a good quality cement based flexible tile adhesive.

It is recommended an epoxy based tile grout is used.

Please ensure the tray is 100% adhered to a supporting flat platform.

Tray must be levelled flat. If necessary weighting of tray whilst adhesive sets may be required.

Shower tray is already primed ready for tiling.